Liquid conditions: Instrumentation

<u>WP4 supported by:</u> C.Voigt (DLR), B.Esposito (CIRA), H.Pervier (U-Cranf), H.Ferschitz (RTA), S.Sawitree (RV), A.Schwarzenboeck (UCF), S.Bansmer (TUBS), T. Neubauer (AIIS)



The project leading to this application has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 824310. This document and its contents remain the property of the beneficiaries of the ICE GENESIS Consortium and may not be distributed or reproduced without the express written approval of the ICE GENESIS Coordinator. R. Heller (DLR)

Icing Instrumentation - Objectives





2

Icing Instrumentation – Target Requirements

Target Requirements to assess the most appropriate instrumentation in Appendix C & O Z icing conditions

Definition of SLD icing conditions documented in the FAR/CS-25 Appendix C & O:

Definition	MVD range	D _{max} range	MVD (50% VD)	D _{max} (99.9% VD)	Max LWC (99.9% LWC)
App. C_stratiform	15 – 40 µm	< 100 µm			0.05-0.8 g m ⁻³
App. C_convective	15 – 50 µm	< 100 µm			0.25-2.8 g m ⁻³
	4.0				
FZDZ_In	< 40 µm	100 – 500 µm	20 µm	389 µm	0.44 g m ^{-s}
FZDZ_In FZDZ_Out	< 40 μm > 40 μm	100 – 500 μm 100 – 500 μm	20 μm 110 μm	389 μm 474 μm	0.44 g m ^{-s} 0.27 g m ⁻³
FZDZ_In FZDZ_Out FZRA_In	< 40 μm > 40 μm < 40 μm	100 – 500 μm 100 – 500 μm > 500 μm	20 μm 110 μm 19 μm	389 μm 474 μm 1553 μm	0.44 g m⁻³ 0.27 g m⁻³ 0.31 g m ⁻³

Definition of W/T performance target:

Instrument uncertainty: Table 2 in D3.1 "Definition of the target requirements" for Test facilities operating envelopes for Appendix O"





Optical Imaging Probes **Optical Scattering Probes**

10000

4

PIP PDI-4D

> HSI FCDP

> > CIP

ADA

2D-S

CAS-DPOL

OAP-260X Mastersizer-X Malvern

- **Selection of instruments**
- Calibration in the lab
- **Testing in wind tunnels**

Challenge:

Ş

- Cover large droplet size range
- Representation of bimodal size distribution
- Improve covering critical size range 50 μm 100 μm



¹Knop, I., Bansmer, S. E., Hahn, V., and Voigt, C.: Comparison of different droplet measurement techniques in the Braunschweig Icing Wind Tunnel, Atmos. Meas. Tech., 14, 1761–1781, https://doi.org/10.5194/amt-14-1761-2021, 2021. ²Jurkat-Witschas, T., C. Voigt, et al., "Aerosol influence on the altitude of glaciation in convective clouds," SAE Technical Paper, presented at the SAE International Conference on Icing of Aircraft, Engines, and Structures, 2019.



- Comparison of instruments in App C
 + App O FZDZ range
- Calibration of instruments





PDI-4D



Rebuild of OAP-260X to 1D2D-X probe

Calibration with Spinning Disk

See presentation "CIRA – Icing Wind Tunnel: WP6 improvement and calibration" ICE GENESIS Public Workshop - 3rd November 2022





App O FZDZ < 40 μ m, ADA small + large size range

ADA: Airborne Droplet Analyzer OAP-260X: Optical Array Probe PDI-4D: Phase Doppler Interferometer with 4 Detectors

CO

5

RTA IWT 8

Ø Several tests in FZDZ/FZRA conditions Comparison of Malvern Spraytec (RTA) Ş and FCDP/2D-S, CAPS-DPOL, PIP (DLR)





CAPS-DPOL: Cloud, Aerosol, and Precipitation Spectrometer with Deploarization FCDP: Fast Cloud Droplet Probe 2D-S: 2D Stereo Probe **PIP:** Precipitation Imaging Probe



10¹

10⁰

ICE GENESIS Public Workshop - 3rd November 2022

 10^{2}

Particle Diameter [µm]

 10^{3}

 10^{4}

10

30

6

FZRA L1 Malvern SprayTec; R² = 0.989 FZRA L1 FCDP/2D-S/PIP; R2 = 0.944

-1:1 Line + 10%

Cumulative Volume Appendix O [%]

CO

60

70

Selection of instruments - Recommendations

Combination of instruments necessary to:

- Cover large droplet size range
- Representation of bimodal size distribution
- Improve covering critical size range 50 μm 100 μm
- Instrument uncertainty for sizing and concentration of particles: about ±15% to ±20%







 CAPS-DPOL: Cloud, Aerosol, and Precipitation Spectrometer with Deploarization

 PDI-4D: Phase Doppler Interferometer with 4 Detectors

 PIP: Precipitation Imaging Probe
 CO
 7

- Selection of instruments
- Calibration in the lab
- Testing in wind tunnels

Challenge:

Z

- Cover wide LWC range: 0.1 3.0 gm⁻³
- Representation of large droplet size spectra and bimodal distributions
- Improve understanding of correction methods for bulk measurements (e.g. collision efficiencies)



¹Lucke, J., Jurkat-Witschas, T., Heller, R., Hahn, V., Hamman, M., Breitfuss, W., Bora, V. R., Moser, M., and Voigt, C.: Icing Wind Tunnel Measurements of Supercooled Large Droplets Using the 12 mm Total Water Content Cone of the Nevzorov Probe, Atmos. Meas. Tech. Discuss., https://doi.org/10.5194/egusphere-2022-647, 2022.



CU-IKP: Cranfield University – Isokinetic Probe **WCM-2000:** Multi-Element Water Content System

CO

Fests @ RTA: Appendix C & Appendix O FZDZ MVD > 40 µm

Total Water Content (TWC) measurements in App C and App O - FZDZ conditions



- Tests @ RTA: Appendix O FZDZ MVD > 40 μm
- Result of several test measurement performed at RTA within ICE GENESIS and before: calculation of a LWC multi instrument mean



CU-IKP and DLR Nevzorov Probe installed inside RTA IWT



Measurement device	deviation from the mean LWC (%)	
Icing Blade	+5.50	
WCM2000 TWC half pipe element	+0.60	
Nevzorov TWC8 cone	-4.70	
Nevzorov TWC12 cone	-19.80	
CU-IKP	+25.50	



CO

10

- Test @ NRC-AIWT; cooperation with CIRA, DLR
 - Comparison of LWC/TWC hot-wire instrumentation in App C and App O FZDZ conditions
 - See presentation "CIRA Icing Wind Tunnel: WP6 improvement and calibration"





Selection of instruments – Recommendations <u>App C:</u> Robust Probe

Instrumentation assessment and selection for LWC measurement (2)

- CIRA: Multi-wire MW, Robust Probe
- RTA: WCM-2000, Nevzorov Probe (, CU-IKP)

Appendix C conditions:

 Agreement between instruments better than ±10% for Isokinetic Probe CU-IKP and multi-wire instruments WCM-2000, Nevzorov Probe and Robust Probe (tests at RTA, CIRA, NRC-AIWT)

Appendix O FZDZ conditions:

 Deviation of individual instruments from a multi-instrument mean less than 25%

Instrument uncertainty: about ±10% to ±15%

U-IKP) than ±10% for Isokinetic Probe M-2000, Nevzorov Probe and C-AIWT)



App C, App O: WCM-2000



CU-IKP: Cranfield University – Isokinetic Probe **WCM-2000:** Multi-Element Water Content System

CO

Global Rainbow technique (GRT) for measurement of droplet temperature

Challenge:

- Development of GRT technique for small and large droplets (bimodal distribution)
- Different model types for use in several wind tunnel dimensions
- Validation of supercooled status of the droplets in wind tunnel test sections, definition of uncertainties



GRT-XL (used outside small IWT) in the lab



- Rainbow angular location of a certain wavelength: function of the refractive index → function of the droplet temperature
- Evaluation of light scattered around the rainbow angle (~138°, for water) enables a measurement of the droplet temperature
- Shape of the light scattered around the rainbow angle depends on the **droplet size**

ICE GENESIS Public Workshop - 3rd November 2022

CO 13

Innovative in Europe

¹ Droplet Temperature Measurements for Efficient Combustors and Icing Safety, Sawitree Saengkaew & Gerard Grehan (rainbowVision), SAE International Conference (AeroTech Europe), September 2020, Bordeaux. ² Supercooled Large Droplets Temperature Measurements by Global Rainbow Technique, Sawitree Saengkaew & Gerard Grehan (rainbowVision), 20th Annual Conference on Liquid Atomization and Spray Systems, December 2020, Ubé, Japan.



- Accuracy of temperature measurement:
 - About 1°C in the lab
 - About 2-3°C in challenging IWT conditions



GRT measurement in TUBS's IWT



Dependence of droplet temperature on the drop size & air temperature



ICE GENESIS Public Workshop - 3rd November 2022

- GRT in large wind tunnel (RTA) for SLD conditions
- Measurement of droplet sizes by GRT has been proven up to 500 µm



Before







15

GRT in large wind tunnel (CIRA) for SLD conditions

- Measurements at -18°C with expected MVD up to 450 µm for bimodal PSD at different simulated altitudes
- GRT-Mini: successful upgraded version to eliminate deposition of fog on optical windows and lens

See presentation "CIRA – Icing Wind Tunnel: WP6 improvement and calibration"





GRT-Mini installed inside CIRA IWT

Validation by numerical simulations @ TUBS

- Validation of simplifications made in GRT measurements
- Proplet final temperature more sensitive to the injection temperature than the injection velocity and the relative humidity
- The larger the droplets are, the larger the range of possible temperature: 300 µm diameter droplet, the possible temperature range: about -5°C to 0°C





Instrumentation for cloud homogeneity characterisation (4)

Review of existing techniques for cloud homogeneity measurements in wind tunnels
Development of new technique @ CIRA: Generalized Scattering Imaging (GSI)

- Challenge:
 - Enhance measurement capabilities to assess cloud uniformity distribution across the test section
 - Development of new, non-intrusive technique for CIRA-IWT

Ice accretion: Icing Grid, Icing Blade @ RTA IWT





ÎCE GENESIS

Instrumentation for cloud homogeneity characterisation (4)

- **GSI** technique characterised and optimised in laboratory tests (CIRA)
- Same conical nozzle as in the CIRA-IWT was used
- GSI technique was shown to measure:
 - size distribution of multi-disperse droplets
 - droplet diameters up to 500 µm
 - a spatial area of 20 cm² x 20 cm²



Multi-disperse droplets: distribution of the number of occurrences of the droplet diameter



"Full" and "string" out of focus images of grouped water droplets of 70 μ m. Each string in the right picture corresponds to a droplet, i.e., to a circular image on the left.

Instrumentation for cloud homogeneity characterisation (4)

LWC Distribution 11 18-08-2018

Windspeed = 60 m/s, LWC = 0.50 g/m³, Freezing Drizzle MVD = 100 µm

1275

Methods @ RTA IWT

Ice Accretion Grid

Examples LWC Distribution: FZDZ MVD > 40 μ m, Windspeed 40, 60 m/s, LWC 0.50 g/m³, 0.64 g/m³, MVD ~ 100 μ m

> Traversing system: Nevzorov Probe









1.5



Instrumentation for 3D-scanning of ice shapes (5)

Development of mobile 3D-scanning system
Development of evaluation tool

Innovative in Europe



- Optimization of 3D-scanning system to be used inside IWT
- Post-processing tool for 2D and 3D scans







¹Neubauer, T., Kozomara, D., Puffing, R.F.A., Hassler, W., "Validation of Ice Roughness Analysis Based on 3D-Scanning and Self-Organizing Maps," SAE Technical Paper, presented at the SAE International Conference, 2019. ²Neubauer, T., Hassler, W., and Puffing, R., "Ice Shape Roughness Assessment Based on a Three-Dimensional Self-Organizing Map Approach," presented at the AIAA AVIATION Forum, 5-19 June, 2020. ³Neubauer, T., and Puffing, R., "Assessment of Ice Shape Roughness via Automatic Spacing of Codebook Vectors in a Two-Dimensional Self-Organizing Map," presented at the AIAA AVIATION Forum, 5-19 June, 2020. ⁴Kozomara, D., Neubauer, T., Puffing, R., Bednar, I., and Breitfuss, W., "Experimental Investigation on the Effects of Icing on Multicopter UAS Operation ", AIAA AVIATION FORUM 2021, DOI: https://doi.org/10.2514/6.2021-2676.



Instrumentation for 3D-scanning of ice shapes (5)

3D-scanning system

- Evaluation of mobile 3D scanning systems Hexagon RS5 and Hexagon RS6
- Development of heating system for scanning head to allow appropriate usage in harsh IWT environments
- Thermal stability of 3D scanning results validated to -10°C in a climatic chamber
- % 3D scanning system global accuracy validated to 40 μm





Arm-based 3D laser scanning system @ RTA IWT





Thermal imaging of RS5 laser scanner during tests in climatic chamber ICE GENESIS Public Workshop - 3rd November 2022

Instrumentation for 3D-scanning of ice shapes (5)

Evaluation tool

- Automatic reporting for ice thickness, mean ice shape, Ş cumulated ice thickness, roughness and ice volume successfully applied
- 2D and 3D ice surface roughness evaluation based on Self-Ş Organizing maps







Mean shape of the ice, ice thickness (examples evaluation tool)



Icing Instrumentation - Objectives



ÎCE

Icing Instrumentation - Open Questions

- Very good progress to select appropriate instrumentation for experiments in SLD. conditions was made within ICE GENESIS
- Further effort to provide additional measurements and involve more W/T Z
- 8 FZDZ: Enhance data statistics for various different conditions to improve the envelope for icing instrumentation
- P FZRA: Provide more measurements and data points to improve statistics and comparisons between different W/T facilities
- FZRA: Enhance W/T cloud drop range in various conditions: low 8 LWC, low droplet number concentration, large droplet sizes
- Further improvements and validation of Global Rainbow Ş technique: Accuracy of temperature measurement from large droplets at different IWT temperatures
- Consider an update of requirements for instrument uncertainty (MVD, LWC)









THANK YOU



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 824310. This text reflects only the author's views and the Commission is not liable for any use that may be made of the information contained therein.

